WellHose®
Easy Drop Pipe

Accessories HANDBOOK

HoseSolutions Inc

CABLE STRAPS

WellHose®
Easy Drop Pipe

The power cable is supported along the length with **WellHose** Cable Straps.

Insert a Cable Strap into every 4th gap along the rib, securing the power cable using a clove-hitch knot. *(As shown in the photo below.)*

Ensure 5% extra total length of power cable to accommodate hose elongation. *(This is equivalent to two "hand's-width" for every strap.)*

When ordering power cable, please remember to include extra length for hose elongation and distance to power supply.

Video Reference
to tie clove hitch:

CENTRALIZER KIT

WellHose®
Easy Drop Pipe

The **WellHose** Centralizer Kit is designed to ensure that the hose and pump remain in the center of the well during operation. It includes a coupler, nipple and rubber spider.

The rubber legs can be cut on-site to suit the well diameter. They will ensure that the top of the pump does not touch the casing.

GRN FITTINGS

WellHose®
Easy Drop Pipe

The **WellHose** fittings have been specifically designed to support the weight and pressure of a pump set in a well.

These fittings are manufactured of Glass-Reinforced Nylon and consist of a double-ring assembly that grip the hose onto the body of the fitting.

NORMAL SIZE	1"	1.25"	1.5"	2"	2.5"	3"	4"
INSIDE DIAMETER	25 mm	32 mm	40 mm	50 mm	65 mm	76 mm	102 mm
MAX DEPTH SETTING	300 ft 90 m	300 ft 90 m	250 ft 75 m	200 ft 60 m	200 ft 60 m	150 ft 45 m	150 ft 45 m
MIN WELL DIAMETER	3 in 75 mm	4 in 100 mm	4 in 100 mm	5 in 125 mm	6 in 150 mm	6 in 150 mm	8 in 200 mm
TORQUE SETTINGS	4 ft.lb 5 Nm	5 ft.lb 7 Nm	5 ft.lb 7 Nm	8 ft.lb 11 Nm	10 ft.lb 14 Nm	12 ft.lb 16 Nm	15 ft.lb 20 Nm

9419 E. San Salvador Dr. #104, Scottsdale, AZ 85258 USA | +1 480 607 1507
Sales@HoseSolutions.com | HoseSolutions.com